



## SY018V DIN Rail Mounted Loadcell Amplifier

### Operating Information

SY018V amplifiers are supplied set up as detailed below unless special instructions are stated on the order. The span and zero presets should not be adjusted unless accurate calibration facilities are available. If the amplifier is supplied with a single loadcell a System Certificate is supplied giving the amplifier output at each loadcell calibration point.

Supply voltage	Maximum	30.0V	
	Minimum	17.0V	
Maximum supply current		185mA	
	<b>Option Code</b>	V 0 0 5	X X
Standard output	Zero load	0.0V	0.0V
	Full load	+5.0V	+10.0V
Bi-directional output	Tension full load	-5.0V	-10.0V
	Zero load	0.0V	0.0V
	Compression full load	+5.0V	+10.0V
Minimum load resistance		10k $\Omega$	
Calibration configuration	24V supply	10M $\Omega$ load resistance	
Non-linearity - Typical		$\pm 0.02\%$ of full range	
	<b>Option Code</b>	V X X X	0 5
Excitation voltage - Nominal		5.0V	10.0V
Maximum excitation current		75mA	150mA
Operating temperature range		0 to 50°C	

### Connections


Terminal	Loadcell Cable	Terminal	Function
A: Ex-	Blue & orange	E: +24V	+ Supply
B: In+	Yellow	F: 0V	Supply 0V
C: In-	Green	G: Output	Output
D: Ex+	Red	H: 0V	Output 0V

In+ and In- colours are shown for a positive output in compression, if a positive output is required in tension reverse the yellow and green wires.

Use good quality screened cable for the output with the screen only earthed at one point. This will usually be at the electronics powering the amplifier.

**THE SUPPLY CONNECTIONS MUST NOT BE REVERSED.**

**DO NOT SHORT CIRCUIT THE AMPLIFIER OUTPUT TO THE POSITIVE SUPPLY TERMINAL.**

 This product complies with the requirements of the European EMC directive.

Document number MN0023 Issue 3 Date 09:11:06

### NOVATECH MEASUREMENTS LTD

83 CASTLEHAM ROAD, ST LEONARDS ON SEA, EAST SUSSEX, TN38 9NT, ENGLAND

Tel: 01424 852744

email: info@novatechloadcells.co.uk

Fax: 01424 853002

www.novatechloadcells.co.uk