



## SY011V Loadcell Amplifier

### Operating Information

SY011V amplifiers are supplied set up as detailed below unless special instructions are stated on the order. The span and zero presets should not be adjusted unless accurate calibration facilities are available. If the amplifier is supplied with a single loadcell a System Certificate is supplied giving the amplifier output at each loadcell calibration point.

Supply voltage	Recommended	15.0V							
	Maximum	16.0V							
	Minimum	14.0V							
	Current limit	<1.0A							
	<b>Option Code</b>	<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>V</td><td>0</td><td>0</td><td>5</td></tr></table>	V	0	0	5	<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>X</td><td>X</td></tr></table>	X	X
V	0	0	5						
X	X								
		<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>V</td><td>0</td><td>1</td><td>0</td></tr></table>	V	0	1	0	<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>X</td><td>X</td></tr></table>	X	X
V	0	1	0						
X	X								
Standard output	Zero load	0.0V	0.0V						
	Full load	+5.0V	+10.0V						
Bi-directional output	Tension full load	-5.0V	-10.0V						
	Zero load	0.0V	0.0V						
	Compression full load	+5.0V	+10.0V						
Minimum load resistance		10kΩ							
Calibration configuration	15V supply	10MΩ load resistance							
Non-linearity - Typical		±0.05% of full range							
	<b>Option Code</b>	<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>V</td><td>X</td><td>X</td><td>X</td></tr></table>	V	X	X	X	<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>0</td><td>5</td></tr></table>	0	5
V	X	X	X						
0	5								
		<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>V</td><td>X</td><td>X</td><td>X</td></tr></table>	V	X	X	X	<table border="1" style="display: inline-table; vertical-align: middle;"><tr><td>1</td><td>0</td></tr></table>	1	0
V	X	X	X						
1	0								
Excitation voltage - Nominal		5.0V	10.0V						
Maximum excitation current		75mA	150mA						
Operating temperature range		0 to 50°C							

### Connections

Terminal	Loadcell Cable	Terminal	Function
Ex-	Blue & orange	Gnd	Supply 0V & output low
Sig+	Yellow	O/P	Output high
Sig-	Green	V+	+ Supply
Ex+	Red		

Sig+ and Sig- colours are shown for a positive output in compression, if a positive output is required in tension reverse the yellow and green wires.

Use good quality screened cable for the output with the screen only earthed at one point. This will usually be at the electronics powering the amplifier.

**THE SUPPLY CONNECTIONS MUST NOT BE REVERSED.**

**DO NOT SHORT CIRCUIT THE AMPLIFIER OUTPUT TO THE POSITIVE SUPPLY TERMINAL.**

This product complies with the requirements of the European EMC directive.

Document number MN0003 Issue 3 Date 02:01:01

### NOVATECH MEASUREMENTS LTD

83 CASTLEHAM ROAD, ST LEONARDS ON SEA, EAST SUSSEX, TN38 9NT, ENGLAND  
 Tel: 01424 852744      email: info@novatechloadcells.co.uk      Fax: 01424 853002  
 www.novatechloadcells.co.uk